17. listopadu 15, 708 33 Ostrava - Poruba, Česká republika Tel.: +420 597 324 467, Fax: +420 324 559 E-mail: marcela.dluhosova@vsb.cz Web: www.340.vsb.cz

NX, Assembly

Description for images: number of description = file name of the corresponding picture. For default NX environment settings.

1.

New: Create a new file type Assembly.

2. - 4

During assembly creating is possible insert 3D models to the assembly from files .PRT.

5. - 6.

Assembly is created and included 1 part.

Assembly Navigator window is on the left side. There are items of assemblies for work with them.

7. - 10

Add: insert a new item do to the assembly from file .PRT.

11. - 15.

Function move Component: change assembly part localization on od assembly space. More kinds of methods for change part localization.

16. - 21.

Assembly Constraint: for definition of constraint/relations between assembly parts.

22. - 23.

Save All: Save a new created assembly file.

Save All: for all opened files.

24.

The new assembly file is created.

25.

Close / All Parts: for all opened files.